























# TYPE MP30

- (D) Montageanleitung
  - (GB) Assembly Instructions
  - (F) Instructions de montage
  - (I) Istruzioni di montaggio
  - (E) Instrucciones de montaje
  - (H) Szerelési utasítás
  - (NL) Montageaanwijzing
- © Copyright by PBO 03/03











852 200



L	N	L <sub>1</sub>	L <sub>2</sub>	H	H <sub>1</sub>
446	408	296	204	721	560
496	458	346	229	921	760
596	558	446	279	1161	1000
696	658	546	329	1441	1280
746	708	596	354	1681	1520
796	758	646	379	1761	1600
996	958	846	479	2041	1880



L	L <sub>1</sub>	L <sub>2</sub>	H	H <sub>1</sub>
446	296	204	721	560
496	346	229	921	760
596	446	279	1161	1000
696	546	329	1441	1280
746	596	354	1681	1520
796	646	379	1761	1600
996	846	479	2041	1880



L	L <sub>1</sub>	H	H <sub>1</sub>
446	296	721	560
496	346	921	760
596	446	1161	1000
696	546	1441	1280
746	596	1681	1520
796	646	1761	1600
996	846	2041	1880

